

AirVantage™ Vest/Liner

Owner's Guide Supplement


Congratulations on your new Aerostich Kanetsu AirVantage™ Electric Vest. For maximum performance, please follow these procedures:

1. Fit - This vest's fit is adjustable with an air filled insert. Inflating the insert will minimize drafts, add insulation, and greatly improve the rate of heat transfer from the electric elements. Add air for a closer fit and increased insulation - release air for a freer fit and reduced insulation.

2. Inflating - The inflation/deflation tube is located under a zipper opening on the upper chest. Blowing into this tube inflates the insert. The more air in the insert, the better the vest will insulate and the closer it will 'hug' your body. When not adjusting the insert's air pressure, keep the inflation tube covered with the attached cap.

3. Deflating/Adjusting - Pressing a fingertip gently against the center of the one way valve located at the end of the inflation tube will reduce the insert air pressure.

4. Deflating for Packing and Storage - Inserting the inflation tube cap backwards (small end in) will keep the one way valve open allowing the vest to be packed compactly or stuffed into its self-store pocket. (illustration A)



5. Custom Shortening the Inflation Tube - Remove the one way valve at the end of the inflation tube (it comes out without tools). Shorten the inflation tube with a knife or scissors and reinstall the one way valve. Custom shortening the inflation tube about 2" is typical. (illustration B)




6. Repairs/Leaks - In normal use the AirVantage™ insert will last the life of the garment. Over long periods it is normal for the vest to very slowly lose its internal pressure. Periodically adding small amounts of air is normal to maintain insulation. If the vest will not remain fully inflated over short intervals (minutes..), it should be repaired. Damaged garments should be returned for repairs to Aerostich galactic headquarters.

7. Long Term Storage - Do not store the vest for extended periods (months or years) tightly folded or compressed within its self-store pocket. For long periods of storage, either hang or fold loosely.

8. Laundry and Care - Hand wash with mild soap or detergent. Gently wring and then air dry.

9. Powercord Routing - Same as regular Kanetsu vests. For additional strain relief, clip the cord to the vest's hem as shown. (illustration C)



10. If you have any questions please contact us at 218 722 1927 or <products@aerostich.com>

11. Go ride your motorcycle.